
取扱の詳細はサングラス本体の取扱説明書をご覧ください。なお、ご不明 な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サービス までお問い合わせください。本説明書は大切に保管してください。

For switching lenses, please see User's Manual included with sunglasses. If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

## レンズの交換方法 Switching lenses



※イラストはノーマルレンズです。 Illustration is the normal model.

大きくえぐられている部分(い部) を先にテンプル側にはめ込みます。 を The large cut out corner (circled area) is inserted into the temple side of the frame



をはめ込み、②ノーズパッド側にレンズをはめ込みます。 Firmly grasp the frame and insert the corner of the lens into the frame.

44-4516-2202

## ⚠注意 CAUTIONS

人が傷害を負ったり物的損害の発生が 想定される内容です。 Under certain conditions, use of this product can result in injury or property damage.

〜偏光レンズは自動車のフロントガラス等の 熱強化したガラスを通して使用すると、ガラス のひずみの干渉色が見えることがありますの

で運転時は注意してください。○暖房器具な ど高温になるところに近づけたり、車中などに 放置しないでください。レンズやフレームが変

質、変形する恐れがあります。○保管する際は 傷つきやすい場所や金属などと一緒にしない でください。レンズに傷がつく原因となります。

OLight can appear distorted when seen through tempered glass, such as the windows of a car. Use caution when driving. OTo prevent deforming

when driving. <a>O</a> | 10 prevent deforming and damage to the glasses, do NOT store in a car or places subject to temperature extremes. <a>O</a> To prevent damage to the glasses, do NOT store with hard or metal objects or in any place that may possibly scratch the

lenses