### 野点セット

### 取扱説明書

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書(以下「本 説明書」といいます)は本製品の正しい取扱方法を説明しています。ご使用の前に 本説明書をよくお読みいただき、正しい使用方法をご確認ください。 なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サー ビスまでお問い合わせください。本説明書は大切に保管してください。



### ■ 特長

お茶を点てるというと敷居が高いように思われますが、特に作法が無く、肩ひじを張 らずに抹茶を楽しめるのが野点です。おいしい沢の水やわき水で、アウトドアならで はの抹茶の味わいと和の風情を楽しめます。またキャンプサイトで出会った人に抹茶 を一服ふるまえば、そこにはたちまち"一期一会"の茶道の世界が広がります。



### 各部の名称/機能説明



# ●茶筅(ちゃせん

#### 見た目が陶器に近く、軽量で強度に優れたメラミン 樹脂を採用。バックパックに無造作に入れても壊れ

抹茶を点てるための携帯性を重視したサイズ の茶筅です。ハードケースも付いており、携行 ることのないタフな茶碗です。仲間と一緒に楽しむと 中でも先が折れにくくなっています。 きは別売の「野点茶碗」を重ねて収納しやすい形状



●茶巾(ちゃきん) 茶碗を清めたりするときに使う布です。

●棗(なつめ) 抹茶を入れるのに最適な内蓋つきのケースです。



●茶杓(ちゃしゃく)

竹で出来た抹茶をすくうものです。専用のケースも 茶碗と蜜、茶筅を置くための台です。不整地でも 安定しておくことが出来ます。赤い盆には茶筅が 付属しています。 倒れないように突起を設けています。

#### ■ 使用方法

●盆

●茶碗

になっています。

● 棗 (なつめ) から茶杓 (ちゃしゃく) で抹茶を2杯 (約2g)ほど茶碗に入れます。

②茶碗にお湯 (70~90℃) を60-70cc ほど入れます。抹茶がダマになってる場合は 茶筅 (ちゃせん) でつぶしてください。

❸片手で茶碗を支えながら、抹茶とお湯がよくまざるように茶筅(ちゃせん)で泡立てます。 ●抹茶の表面が、きめ細かく泡立てば完成です。温かいうちにお飲みください。 \*お好みで濃さや温度などを調節してください。

#### ■ 安全上の注意 Ø ゆずお読みください

**注** 人が傷害を負ったり物的損害の発生が想定される内容です。

#### 茶碗

- ○電子レンジ、オーブン、直火や電熱調理器にかけたり、火のそばに置かないでください。 ○落とす、ぶつけるなど強い衝撃を与えないでください。
- ○初めて使用になる前に、食器用洗剤を含ませた柔らかいスポンジなどでよく洗ってください。

○硬い回転ブラシやたわし、磨き粉、研磨剤スポンジで擦るとキズが付きますので使用しない でください。

○塩素系漂白剤は食器の光沢が落ち、黄ばみの原因になりますので酸素系漂白剤を使 用してください。

○食品の色素が移行しますので、使用後は長時間の放置は避けてください。

#### 茶筅、茶杓

○この製品に同封している竹の茶道具は、自然素材を使用しているため、極度の乾燥 による割れや、温度や湿度の条件によってはカビが発生する場合があります。

#### ■ 保管方法

#### 茶碗

○直射日光を避け、湿気の少ない場所に保管してください。

#### 茶筅、茶杓

○乾いた布などで汚れを落とし、直射日光やエアコンの風を避け、高温多湿に ならない涼しい場所で保管してください。

### ■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点が ございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡く ださい。製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、 修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。なお、 以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

○本製品の誤った使用方法によるもの

○間違ったお手入れ、保管方法、経年変化による素材劣化

○乱暴な取り扱いによるもの

○ その他、 製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させ ていただきます。

#### ■ 仕様

#1124422 野点セット 【容量】330mL 【耐熱温度】120℃ 【耐冷温度】-30℃ 素材 茶碗:メラミン樹脂 茶筅、茶杓:天然木(竹) 台:天然木

#### ■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量な どのスペックには誤差が生じる場合があります。

株式会社 モンペル 本社 〒550-0013 大阪市西区新町 2-2-2 商品についてのお問い合わせはカスタマー・サービスまで Tel. 06-6531-3544 フリーコール: ④ 0088-22-0031 モンベルホームページ http://www.montbell.ip

### **Nodate Set**

### mont-bell

#### User's Manual

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product. If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.



### Enioving Nodate: Open-air tea ceremony

Tea ceremony may have the image of having a high barrier of entry. but Nodate is held picnic-style in the outdoors, doesn't have much in the way of rules, and doesn't need to be performed strictly. A cup of matcha made using water from a mountain stream or bubbling spring is a great way to enjoy the elegance of the ceremony. Also sharing a cup of matcha with people met around your campsite is an excellent way to create once-in-a-lifetime memories.



### Components/Features







Bon / Trav Tray for placing the chawan, chasen, and natsume on. Has good stability even on uneven ground. The red trav has a peg for preventing the chasen from tipping over.

### Directions / Preparing Tea

- OUse the chashaku to scoop out two spoonfuls (about 2 grams) of matcha from the natsume into the chawan
- 2 Pour 60-70mm of hot water (70-90°C). Break up any lumps of matcha using the chasen.
- BHold steady the *chawan* in one hand and use the *chasen* to whisk together the hot water and matcha.
- Stop whisking once the surface of the matcha has become slightly frothy. Drink while hot

\*Adjust thickness of tea and temperature to preference.

### Safety Warnings!

#### Please read carefully.

Under certain conditions, use of this product can result in injury or property damage.

#### Chawan -

ODo NOT place in a microwave, oven, direct flame, or induction cooking surface. ODo NOT place near flame. ODo NOT drop or apply strong shocks or force.

OBefore using for the first time, wash with a soft sponge and soap.

- ODo not use hard bristled brushes, metal scrubbers, metal polish, or abrasive sponges to clean.
- ODo NOT use chlorine-based bleach. Will cause the finish to deteriorate and cause a vellowish tint. Use only oxygen-based bleach.
- OMay stain fade if not cared for or stored properly after use.

#### Chasen and Chashaku

OThe *chasen* and *chashaku* are made using natural bamboo. These tools can break if bamboo dries out completely and can mold if exposed to high humidity or high moisture.

### Storage

#### Chawan -

OWhen storing for an extended period of time, store in a well ventilated. cool, dry place out of direct sunlight.

OWipe clean with a dry cloth and store in a well ventilated, cool, dry place out of direct sunlight and away from air conditioning.

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at our discretion. This warranty does not cover damage(s) caused by accident. improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

### Specifications

#1124422

#### Nodate Set

Volume: 330ml Heat Resistance: 120°C Cold Resistance: -30°C

Materia

Chawan: Melamine resin Chasen and Chashaku: Natural bamboo Bon: Natural wood

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

### mont-bell Co...Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN www.montbell.com

## Chasen and Chashaku

## Warrantv

Chashaku / Tea Spoon Bamboo spoon for scooping matcha. Comes with its own carrying case.

Natsume / Tea Caddy

and includes an inner lid.

This caddy is perfect for transporting matcha