

44-2709-1711

mont.bell User's Manual Stoppers for Alpine Carbon Pole

Stoppers for Alpine Carbon Pole

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

Features

These are replacement stoppers for the twist locking Alpine Carbon series of trekking poles.

*Not compatible with models made before 2017.

Please see website for compatibility details.

*Only compatible with Montbell trekking poles.

Components



Safety Warnings! Please read carefully.

CAUTION: Under certain conditions, use of this product can result in injury or property damage.

ODo NOT apply lubricants to the stoppers. If the shaft is not properly locked, the shaft can come apart or slide closed during use and result in a falling accident.

Ostore out of the reach of children.

OStoppers are a choking hazard for small children.

Directions % Please also reference the user's manual included with your trekking pole.

Stoppers may not perform as intended and require replacement if they become too worn or caked with dirt or other debris.

Stopper

Pull open the

sides of the

stopper.

Turn the lower shaft counterclockwise to loosen and remove from the middle shaft. Do the same for the middle shaft removing it from the upper shaft.



Remove the old stopper from the middle and lower shaft.



Then proceed to open the other sides of the stopper.

ceed to open Remove the sides of the stopper.

To replace the new stopper onto the middle and lower shaft, follow the reverse procedure in 2.
Screw tab Tab

Stopper Size Middle shaft : Large stopper (Blue) Lower shaft : Small stopper (Orange)

Make sure that the black piece of the trekking pole is top-centered in between the four slits of the stopper as shown in the illustration below. For adjustments, pinch the stopper towards the center.



Lock

Solution Insert the lower shaft into the middle shaft and turn clockwise to lock in place. Do the same for the middle shaft and turn clockwise to lock in place.

(Stopper)

opening slit

Upper

Lock

Place your weight on the pole to see that the stoppers are performing as intended and have securely locked the shafts in place. Loosen and slide close both the bottom and middle shafts.

Turn clockwise to lock in place. Loose shafts can become dislodged and fall.

After replacing the stoppers and the pole still isn't locking securely, there may be another cause, such as dirt or debris on the inside of the pole. Please contact Montbell Customer service.

Storage

○For long term storage, store in a well ventilated, cool, dry place away from direct sunlight. ○To prevent deforming and damage, do NOT store near heat sources.

Disposal

 \bigcirc Please follow local regulations regarding waste disposal.

Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at its discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear.

Damage(s) not covered under warranty will be repaired at a reasonable rate.

If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

Specifications

Style#: 1124750

Name : Stoppers for Alpine Carbon Pole

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

