

■ 保管方法

- 高温になる場所を避け、風通しの良い場所に保管してください。
- ガソリンやシンナーと一緒に保管しないでください。

■ 廃棄方法

- 廃棄方法はお客様の自治体の収集方法に従ってください。

■ アフターサービス

お問い合わせいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お問い合わせいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

■ 仕様・サイズ

| 【品番】 | 【品名】 |
|----------|--------------|
| #1133295 | リッジライン バック30 |
| #1133296 | リッジライン バック40 |

【素材】本体/210デニール・ポリステティック®・ナイロンリップストップ [ウレタンコーティング]
本体/420デニール・ポリステティック®・ナイロンリップストップ [ウレタンコーティング]

■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

mont·bell

取扱説明書

リッジラインバック 30・40

Ridge Line Pack 30・40

この度はお問い合わせいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

軽量ながら強度に優れたポリステティック®ナイロンを使用したバックパックです。縫い目部分に目止め処理を行い、耐水性を上げています。1泊程度のテント山行からトレッキングまで幅広く対応します。40はフレームを内蔵することにより安定したフィット感を実現。30Lは背面パッドを取り外してサブザックとしても使用可能です。バックパックの上部を覆う専用バックカバー付き。

※本製品の本体部分は縫い目を目止めしており高い耐水性を誇りますが、完全防水ではありません。また開口部のジッパーまわりは一般的なバックパックと同様に縫い目の目止めを施していないため、付属のバックカバーをご使用ください。雨中の行動が長時間に及ぶような場合に浸水する恐れがありますので、ご使用の状況に応じてスタッフバッグなども併用してください。

■ 各部の名称

※写真は40Lです。



■ 安全上の注意 必ずお読みください

警告 場合により人が死亡または重傷を負う可能性が想定される内容です。
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本製品の改造や分解などは絶対にしないでください。性能が損なわれ、充分に能力が発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。

注意 人が傷害を負ったり物的損害の発生が想定される内容です。

- 本製品の上部は一般的なバックパックと同様に縫い目の目止めを施していません。ご使用の状況に応じて付属のバックカバーの他、スタッフバッグなども併用してください。
- 使用前は毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合は直ちに本製品の使用を中止してください。本来の性能が発揮できない恐れがあります。


使用前の点検 使用にあたっては、毎回必ず次のことを確かめてください。
異常が見られた場合は使用しないでください。

- 本体やテープに破れがないか
- バックルに破損がないか


■ 使用方法

○トレールウォーターパック(別売)取り付け方法

トレールウォーターパックは荷物を降ろさずに行動しながら水分補給ができる、チューブで給水するソフトタイプのポトルです。装着の際はトレールウォーターパックに付属の取扱説明書も併せてご覧ください。



トレールウォーターパックのライドパーツのフックを荷室内上部、図の黒色ループに掛けて装着し、本体側通し穴を通して荷室の外にチューブを出します。




チューブをショルダーハーネスのループ(A)に通し、飲み口の位置を調節します。チェストサポートに付いている固定用クリップ(B)も併用します。

※図は40Lです。


○上部バックカバーの取り付け方法



背面上部バックカバー収納部からバックカバーを取り出し、本体のロゴとカバーのロゴが合うようにかぶせます。



左右のショルダーハーネスのループにカバーのフックを引っ掛けます。同様に本体前面のループにもフックを留めて固定します。荷物の量に応じて前面のフック位置を調節してください。




※本製品の本体部分は縫い目を目止めしており高い耐水性を誇りますが、上部は一般的なバックパックと同様に縫い目の目止めを施していません。

○フィッティングの手順

バックがジャストフィットしている状態とは、バックパネルとショルダーハーネスが体に隙間無く接している状態のことをいいます。ご使用にあたっては、ご自身の体格に合わせて、適切なフィッティングを行ってください。

本製品の各バックルに通したテープをあらかじめ適度に緩めておきます。また、実際の使用状態での正しいポジションを得るために、まず 10kg 程度の荷物をバックに入れます。



① パックを背負い、腹部を圧迫しないように腰骨部分でヒップベルトを締める。

② ショルダーハーネスが体にフィットするようにショルダーストラップを引く。


③ このとき、バックと背中との間に隙間があるようならフレームを調節してください(40Lのみ)。

④ ショルダースタビライザーを引き、上部の重心を体に引き寄せ安定させる(40Lのみ)。

⑤ ショルダーハーネスを安定させるためにチェストサポートを留める。

フレームの調節(40Lのみ)

本製品に内蔵されているアルミフレームは、あらかじめ体の背面のカーブに合わせて曲げています。ほとんどの場合はそのままご使用いただけますが、本製品と体の間に隙間がある場合は以下の手順でアルミフレームを曲げてください。



○荷物を取り出して空荷の状態にして、本製品に内蔵されているアルミフレームを曲げます。体との隙間がなくなるように脚などを使って曲げていきます。

※アルミフレームは本製品から取り出さないで本体ごと曲げてください。

※一度に大きく曲げるのではなく、少しずつ曲げてください。

○アルミフレームの調節後、手順を①からやり直します。

以上で、本製品の基本的なフィッティングは完了です。ただし、各テープ類の長さは身につける服によっても変わりますので、その都度の微調節が必要です。苦しくならない範囲でしっかり締めてください。

■ お手入れ方法

○背面の汗による汚れや泥の汚れは水で軽く洗い流した後に中性洗剤を含ませたスポンジでブラッシングをし、洗剤を洗い流してから陰干しして下さい(ドライクリーニングはできません)。

○ドライクリーニングや洗濯機による洗濯はしないでください。生地を傷める恐れがあります。

○乾燥機を使用しないでください。熱でシームテープが劣化し、製品の寿命を縮める恐れがあります。

○撥水スプレーは使用しないでください。生地表面のコーティングによって、撥水成分が定着しません。また、スプレーの種類によっては表面のコーティングを傷める恐れがあります。

■ Storage

- Store in a well ventilated, cool, dry place.
- Do NOT store together with gasoline or paint thinner.

■ Disposal

- Please follow local regulations regarding waste disposal.

■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

■ Specifications

| [Style] | [Name] |
|----------|--------------------|
| #1133295 | Ridge Line Pack 30 |
| #1133296 | Ridge Line Pack 40 |

[Material]

Main / 210-denier urethane coated rip-stop Ballistic nylon
Bottom / 420-denier urethane coated rip-stop Ballistic nylon

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN
<https://www.montbell.com/>

mont-bell

Ridge Line Pack 30·40

Ridge Line Pack 30·40

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.


■ Description

Featuring an easy-access zip top, lightweight Ballistic nylon delivers strength and durability, providing great all-around use on overnight backpack trips and day hikes. The 40L has a built-in frame to increase stability on the trail. The 30L features a removable back pad, improving pack-ability and allowing versatile use as a summit pack. Seam-sealed and includes a specially designed rain cover to enhance water resistance.

*The Ridge Line Packs are seam sealed to enhance water resistance. However the top zipper is not seam sealed and water may eventually penetrate into the backpack under certain conditions, for example if used for an extended period of time in the rain. Consider using waterproof stuff sacks for added protection.

■ Components

※40L Model



■ Safety Warnings! Please read carefully.

⚠ WARNING! Under certain conditions, use of this product can result in injury, death, or property damage.

- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair functionality.
- Please follow recommended care and storage instructions. Improper care and storage can lead to a decrease in performance.

⚠ CAUTION! Under certain conditions, use of this product can result in injury or property damage.

- Although this product has a high degree of weatherproofing, it is not completely waterproof. Water can eventually penetrate into the backpack, for example if used for an extended period of time in the rain.
- Prior to use, check the product's condition and stop using immediately if you notice any deterioration from age/use, damage or irregularities.


■ Before using, check for;

- Damage to the fabric Damage to the buckles


■ Directions

- This pack is compatible with the Trail Water Pack (sold separately)

A hydration bladder with a tube that allows you to drink while moving, without needing to put your pack down. When installing, also refer to the Trail Water Pack instruction manual.



Hang the hook connected to the Trail Water Pack from the loop on the inner hook as shown in the figure.




Pass the hose through the loop on the shoulder harness (A) and adjust the position of the mouth piece. The hose can be clipped on to the sternum strap (B).


- Attaching rain cover



Take the rain cover out of the pocket at the top of the back panel and align the montbell logo on the front panel logo to attach correctly.




Attach the rain cover's hooks to the loops on the left and right shoulder harness. Depending on the volume of the pack, attach the clips to the loops on the front panel.



*The Ridge Line series features seamed seals for improved water resistance. However the back panel and top of the backpack are not seam sealed and these areas have water resistance equal to that of standard backpacks.

Adjusting the stabilizers

Before starting, unbuckle and loosen all straps. To simulate conditions during actual use, load about 10kg of weight into the backpack.



Put the pack on, then fasten the hipbelt with it sitting on the hipbone.

Pull the shoulder straps so that they tighten around your shoulders and armpits.


If there are gaps between the backpack and your back, make adjustments to the aluminum frame. (40L size only)

Pull the load lifters to draw the backpack's center of gravity in closer to your body. (40L size only)

Fasten the sternum strap to secure the shoulder harness in place.

Adjust the aluminum frame (40L size only)

The aluminum frame inside this product has been pre-bent to fit the curve and shape of the back. In most cases, it can be used as it is. If there are any gaps between the backpack, your shoulders and back, please use the following instructions to make any necessary adjustments.



Remove all items inside the backpack and be sure to perform any adjustments when the backpack is empty. Check the location of the aluminum frame (see illustration below) and bend it while inside the backpack using your legs.

- Do not remove the aluminum frame.
- Make sure to bend the left and right sides of the frame at the same time.
- Make minor, gradual adjustments to the frame and avoid swift, major adjustments.

The fitting of your backpack is now complete. Depending on what you wear you may need to make minor adjustments to the shoulder straps, load lifters, and hipbelt straps. Fasten straps so that they are secure, but do not cause discomfort.

■ Care

Improper care and storage will shorten the lifespan of this product. Please review the following instructions for care and storage.

- To clean stains and soiling, lightly rinse off and use a mild soap with a sponge to brush away any remaining residue. Rinse off and dry in the shade. Do NOT dry clean. This can damage the product's fabric.
- Do NOT dry clean or wash in a washing machine. This can damage the product's fabric.
- Do NOT dry in a dryer. Heat can cause the seam seals to deteriorate and shorten the product's lifespan.
- Do NOT use water repellent spray. The fabric's outer coating won't allow water repellent agents to penetrate. Certain water repellent agents could have adverse effects on the fabric's coating.