

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書(以下「本説明書」といいます)は 本製品の正しい取扱方法を説明しています。ご使用の前に本説明書をよくお読みいただき、正しい使用 方法をご確認ください。なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・ サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

本製品はフォールディングカヤックやツーリングカヤックに適した軽量コンパクトなパドルです。 組み立てが容易な2ピースモデルと携行に便利な4ピースモデルを展開しています。オーシャンパドルは ブレードの幅が狭く水の抵抗を抑えることができるため、長時間漕ぎ続けるシーンに適しています。

■各部の名称





2

44-4475-2107



Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product. If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

Description

A lightweight, compact kavak paddle ideal for use with folding and touring kavaks. The 2-piece paddle is simple to assemble, and the 4-piece paddle is easily portable. Narrower blades create less resistance in the water, making the paddle suitable for long-distance touring.

Components



Safety Warnings! Please read carefully.

Danger!

Under certain conditions, use of this product can result in major injury or death.

OPaddling sports are inherently dangerous, possibly resulting in injury or death. Anyone using this product or related products should be aware of the risks involved. To prevent accidents, carefully read and follow the instructions in this user's manual.

ODue to the characteristics of this product, it is not suitable for intense use that may place excessive loads on the product.

OBe aware of tidal changes and strong currents along coastlines. When kayaking on a lake, river, or coast, unexpectedly strong and sudden winds may occur due to weather changes. Be aware of the characteristics of kayaks and your own physical capabilities for safe use.

Under certain conditions, use of this product can result in injury. Warnings! death, or property damage.

OThis product is designed for paddling a kayak. Do NOT use for any other purposes.

Be aware of your surroundings to prevent property damage and injury to yourself and others.

OPrior to use, understand how to use the product and practice using it in a safe place. May result in injury or damage if not familiar with proper use.

 \bigcirc Do NOT alter or modify this product in any way. May cause injury or damage.

Under certain conditions, use of this product can result in injury CAUTION! or property damage.

- O Do NOT put your full weight on the paddle when getting in and out of a kayak.
- OThis product may be damaged if used in shallow water or places where it could strike against rocks.
- OExposure to high water pressure or submersion in water for extended periods of time may result in water penetrating the shaft.

Prior to use, inspect this product for:

Cracks, damage and other signs of wear and tear. Loosening of the screw on the lever-type ferrule.

Directions

(1)Connect the left and right blades and shafts with snap-button joints. (4-piece paddles only) Snap-button

⁽²⁾The left and right sides are connected with the lever-type ferrule. Adjust the shaft to your desired length and blade angle, then tighten the lever (Fig.A).

Fig.A

Fig.B

Lever

Fig.C

Adjusting the lever-type ferrule If the joint is still loose after securing the lever, tighten the screw in the lever. If excessively tightened, may cause damage to the clamps.

Guidelines for paddle feathering (blade angle)

Adjusting to a higher number setting will create a bigger angle between the blades, resulting in less wind resistance. However, this will also put greater strain on the wrists. Please adjust the angle depending on conditions.



○Strong wind conditions : 60° to 80° (Fig. C)

Make sure snap-button(s) is securely inserted. The shafts may detach during use if snap-button(s) is not inserted correctly. 4-piece paddles only Be careful not to pinch your fingers when assembling.



Improper care and storage can shorten the lifespan of this product. **Care** Follow the recommendations below to extend the lifespan of your product.

○After use, take apart the paddle, clean and wash with fresh water, then dry.

- Olf used in seawater and left assembled for extended periods, salt may crystallize and cause the joints to become stiff. After using in the sea, wash the entire paddle thoroughly with fresh water to remove salt content.
- Joints may become stiff with repeated use. If this happens, apply a silicone spray to joint areas only.

Storage

 \bigcirc Store in a well-ventilated, cool, dry place away from direct sunlight.

ODo NOT expose this product to temperature extremes, such as in a car in summer. May cause deformation and damage.

Disposal

OPlease follow local regulations regarding waste disposal.

Warrantv

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect. Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear, Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

Specifications

Style#	:#2351112	#2351117	#2351122
Name	: Yukon Carbon Fiber	Yukon Carbon Fiber	Ocean Carbon Fiber
	Paddle 2-Piece	Paddle 4-Piece	Paddle 2-Piece
Material: [Shaft/Blade] Carbon fiber reinforced regin			

Material: [Shaft/Blade] Carbon fiber reinforced resin

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.



CAUTION! Do NOT adjust the length beyond 10. An excessive load will be applied to the joint sections, resulting in damage.

Ē-10